

W1 = 1'-3''

W2 = 10" FOR VERTICAL CLEARANCE THRU 10'-0"

W2 = 12" FOR VERTICAL CLEARANCE OVER 10'-0"

W3 = L - W2 - W4

W4 = (X) SINa

W5 = WIDTH OF FTG. AT END OF WING = $\frac{H3 + F1}{2}$


W6 = WIDTH OF FTG. AT END OF WING = $\frac{H1 + F1}{2}$

FTG. DIMENSION FROM BACK OF WALL TO FRONT OF FTG. = 1/3 TOTAL WIDTH (8" MIN. FROM FRONT OF WALL TO EDGE OF FOOTING)

FTG. DIMENSION FROM BACK OF WALL TO BACK EDGE OF FTG. = 2/3 TOTAL WIDTH (9" MIN.)

LAYOUT FOR TURNED BACK CULVERT WINGS

FIGURE 9 - 13



W3 = L - W2 - W4

W4 = (X) SINa

W5 = WIDTH OF FTG. AT END OF WING = $\frac{H3 + F1}{2}$

W6 = WIDTH OF FTG. AT END OF WING = $\frac{H1 + F1}{2}$

FTG. DIMENSION FROM BACK OF WALL TO FRONT OF FTG. = 1/3 TOTAL WIDTH (200mm MIN. FROM FRONT OF WALL TO EDGE OF FOOTING)

FTG. DIMENSION FROM BACK OF WALL TO BACK EDGE OF FTG. = 2/3 TOTAL WIDTH (225mm MIN.)

LAYOUT FOR TURNED BACK CULVERT WINGS